<u>EG-Keeper マスクチェックの外し方</u>

日本語ファームウェアの場合

ログイン後、

①設定 → ②アルゴリズム → ③システムパラメーター →

④ 一般設定の「チェック項目の設定」から

『 □マスク検出を有効にする ⇒ □マスク検出を有効にする 』

チェックを外して、⑤『<mark>保存</mark>』をクリックしてください。

:	
■ システム	認証パラメータ パネル設定 閾値温度設定 アクセス制御
● 通信	一般設定
9 カメラ	チェック項目の設定
🔟 映像	☑ 有効
6 PUJUZA 2	測定実施間隔(ミリ秒) 2000
22 登録データ	✓ 体温測定を有効にする
💟 アップロード	□ マスク検出を有効にする ● ④ チェックを外す
	認証設定
	認証間隔(ミリ秒) 2000
	ログ保存設定
	✓ 登録者のログを保存
	ログ保存間隔(分) 0
	✓ 未登録者のログを保存
	IDカード読み込みモード
	IDカード読み込みモード None イ
	HIDデバイス読み取りモード
	HIDデバイス読み取りモード IDカードリーダー v
	☐ 保存

英語版ファームウェアの場合

ログイン後、

(1)Configuration \rightarrow (2) Algorithm \rightarrow (3)Capture Settings \rightarrow (4)Normal Settings

の「Attribute Settings」から $\boxed{\Box}$ Mask Attribute \Rightarrow \Box Mask Attribute

チェックを外して、⑤『<mark>SAVE</mark>』をクリックしてください。

	Preview Configuration
🖽 System	Capture settings Threshold Settings Server Settings Cloud Settings Panel Settings
Communication	Camera0 V
🔮 Video	Grab Configuration
🖬 Image	Target picture settings
Algorithm (2)	◯ customize ● Mug shot ◯ Half-length photo ◯ full-body shot
Face Database	Target image size
	width: Face width × 1.5 (1.0-5.0)
	Face part height: Face height × 1.5 (1.0-3.0)
	Body parts Height: Face height × 1 (0.0-10.0)
	Fixed pixel Image Width 100 × Image Height 100 (0-1000)
	Background settings
	Image Quality general V
	Picture resolution 720P(1280*720)
	Background image upload
	Capture Img Upload
	Infrared Img Upload
	✓ Register Img Upload
	Normal Settings
	FaceAE Settings
	Z Enable
	Temperature Settings
	Show Infrared Image
	Take Infrared Image Take Button
	Attribute Settings
	Attribute Interval (ms)
	Mask Attribute (4)チェックを外す
	Recognize Settings
	M Enable Store Strange
	ID Reader Link Mode
	ID Reader Link Mode None V
	Save (5)